

Bendix Fuel Servo Piece Parts

Part Number	Description of Part Number
CF177718	Washer, Spring
CF199596	Washer, Flat
CF2520625	Spring, Constant Head
CF2520652	Spring, Constant Effort
CF2522021	Pin, Clevis
CF2522022	Pin, Clevis
CF2523155	Spring, Constant Head
CF2523247	Spring, Constant Effort
CF2523387	Spring, Constant Head
CF2523688	Spring, Constant Effort
CF2525165	Spring, Idle Linkage
CF2525494	Packing, Preformed
CF2526388	Diaphragm, Flow Divider
CF2526413	Stop Assembly - Throttle
CF2526429	Packing, Preformed
CF2537608	Strainer Assembly, Fuel Inlet
CF2537610	Strainer Assembly, Fuel Inlet
CF2537779	Spring, Constant Head
CF2537968	Spring, Constant Effort
CF2538283	Seat Assy.
CF2538295	Diaphragm Assy.
CF2538298	Bushing
CF2538330	Washer, Nonmetallic
CF2538420	Diaphragm Assy.
CF2539115	Washer, Shim
CF2539512	Spring, Constant Effort
CF2539560	Spring, Helical Comp.
CF2539561	Seal, Servo Stem
CF2539738	Pin, Spring
CF2539804	Holder, Spring
CF2540537	Bellows Assembly
CF2540538	Bellows Assembly
CF2540542	Bushing
CF2540576	Bushing-Mixture Control
CF2540577	Seal - Mixture Control
CF2540578	Plate - Mixture Control Bushing
CF2541053	Lever Assy.-Mixture Control
CF2541265	Valve, Mixture Control
CF2541439	Spring, Constant Head
CF2541562	Valve, Mixture Control

Bendix Fuel Servo Piece Parts (Cont.)

Part Number	Description of Part Number
CF2541563	Valve, Mixture Control
CF2541564	Valve, Mixture Control
CF2541801	Diaphragm Assy., Fuel
CF2541803	Diaphragm Assy., Fuel
CF2542391	Name Plate, Service
CF365533	Gasket
CF367726	Washer, Shim
CF367757	Washer
CF383493	Plug, Hex
CF393849	Screw, Fill Head
CF901200	Cotter Pin
CF901209K1	Cotter Pin
CF909290	Pin, Spring
CF951392	Packing, Preformed
CF951394	Packing, Preformed
CF951400	Packing, Preformed
CF951401	Packing, Preformed
CF951437	Packing, Preformed
CF951787	Packing, Preformed
CF951789	Packing, Preformed
CF951790	Packing, Preformed
CF953516-10	Packing, Preformed
CF953516-8	Packing, Preformed
CF953541-10	Packing, Preformed
CF953541-8	Packing, Preformed
CFK-10AD1	Fuel Servo Quick Kit - All RSA-10AD1 Models
CFK-10DB2	Fuel Servo Quick Kit - All RSA-10DB2 Models
CFK-10ED1	Fuel Servo Quick Kit - All RSA-10ED1 Models
CFK-10ED2	Fuel Servo Quick Kit - All RSA-10ED2 Models
CFK-5AB1	Fuel Servo Quick Kit - All RSA-5AB1 Models
CFK-5AD1	Fuel Servo Quick Kit - All RSA-5AD1 Models
CFP19821	Washer, Spring
CFP22198	Washer
CFP4235	Screw